

# Dollhouse (club) project

## Deluxe Bathroom

Learn how to construct & create an authentic looking victorian bathroom from Miniature MarketPlace with water effects on tap using special adhesives & scenic products from Deluxe Materials

By Candy Chapill



### Product list. All available from Miniature MarketPlace.

- Chrysnbon Bathroom Set                    **CB2111**
- Deluxe Plastic Magic                    40ml    **DAD77**
- Deluxe Rokat Plastic Glue            30ml    **DAD62**
- Deluxe Aqua Magic                    125ml   **DBD65** OR **DBD64** 250ml
- Deluxe Solid Water                    90ml    **DBD35**
- Deluxe Making Waves                100ml   **DBD39**

**1.** All the products listed shown here.

**2.** Use Deluxe Materials Plastic Magic to assemble the stool. It is ideal for close fitting joints as it bonds immediately with an invisible glue line. The bathroom cabinet was assembled similarly.

**3.** Again using Deluxe Materials Plastic Magic, assemble the radiator. Identify & join the four centre sections first. The fine point brush

is perfect for this slightly more intricate join.

**4.** To join the toilet bowl, use Deluxe Materials Rokat Plastic Glue. It is perfect for this particular join as it allows a longer working time & can be spread thinly over both sides of the bowl without instant evaporation.

**5.** Going back to Deluxe Materials Plastic Magic, use this to assemble the toilet cistern. This is ideal for this

particular step as it creates a nice strong bond for a slightly tricky & intricate join.





**6.** Use Deluxe Materials Plastic Magic to assemble the sink, including the taps. The fine point brush is in its element here, as securing the taps can be a little fiddly.



**7.** Once all pieces are dry, arrange your bathroom ready for the addition of Deluxe Materials Aqua Magic, Solid Water & Making Waves. I added a small piece of Blu-Tack to the bottom of the toilet to create a seal.



**8.** To add water to your sink & toilet, use Deluxe Materials Aqua Magic. This is ideal for shallow water & can be built up in layers. It needs no mixing, so just pour it straight in. I did mine in three layers.

**9.** For deeper water, such as your bath, use Deluxe Materials Solid Water.

Measure ACCURATE volumes (2 parts resin to 1 part hardener), & mix together well before pouring. For more accuracy measure volumes on scales.

**10.** To add a running water effect, use Deluxe Materials Making Waves. Using a syringe with a fine needle point, carefully extrude some at the tap and allow to fall onto the dry Aqua Magic. It dries clear, & more layers & ripples can be added once dry.



**11.** The finished bathroom with an Aqua Magic puddle!



**TOP TIPS** "For mixing Solid Water always make sure the 2 parts resin to 1 part hardener is ACCURATELY measured either by volume or weight (adding more hardener will not shorten the setting time)."